



EMX-30

USB Tethered Iris Recognition System for Desktop and Countertop Applications

Product Description

The CMITech EMX-30 is a USB tethered dual eye iris biometrics imaging device that quickly captures highest quality iris biometric images. Easy to use, the system's simple and intuitive user interface makes positioning fast and repeatable, even for subjects with little or no acclimation. The advanced image capture and processing architecture offers the fastest iris biometric capture speeds in the industry.

Operating at a range of 32 to 35 cm, the EMX-30 is fully hands-free and contactless. The exclusive face-finding functionality locates each subject's position and automatically tilts the imager head to adjust for subject height. This functionality is optical, which allows the EMX-30 to be placed behind an optical glass or plastic window, making it ideal for placement behind an environmental shield.

Developed with the latest in system design technologies by one of the leaders in the industry, the EMX-30 is physically robust, highly reliable and durable. It is configured as a USB tethered device, making the EMX-30 highly cost effective.



Key Features User Advantages Feature State-of-the-art optical design The optical design includes utilizing highest quality optics and very fast shutter speeds, which allows the systems to exceed industry standards for image quality. The measured modulation transfer function exceeds the specification in the ISO 19794-6 standard of 4.0 lp/mm at 60% contrast ratio. Advanced, proprietary The EMX-30 accurately locates the position of both eyes in 3D in stereoscopic eye localization near-real time to optimize subject ease of positioning and iris image quality. This feature enables the fast and reliable subject distance positioning indicators. Simple and repeatable subject Subject positioning is simple and intuitive. The subject merely aligns his user interface / her eyes with the positioning mirrors, and then moves toward or away from the system based on simple, colored LED indications: Blue is too far away Red is too close and Green is OK. Simplest of user instructions The combination of the easy to use positioning features also means that the instructions to subjects are simple and straightforward. (See User Interface and Subject Instructions.) Proprietary optics for positioning The proprietary and patented design of the color LEDs for distance indicators eliminate parallax positioning can only be viewed by one eye at a time, eliminating viewing problems any parallax viewing problems that might cause the subject to reposition his / her head. The result is a smooth and intuitive positioning experience, even if the subject's head is positioned slightly to one side. Automatic vertical height The system accommodates subjects of different heights. After automatically locating the subject's face and eyes, the EMX-30 tilts the iris adjustment imaging subsystem. This function is optical, which allows for utilization behind optical glass or plastic shielding. Stand-off distance of 32 to 35 cm Comfortable range for subjects in wide variety of kiosk, desktop or countertop placements Large depth of capture of 30 mm The very large depth of capture enhances robustness and ease of

positioning.

High speed, simultaneous dual iris
image capture sensors

Both iris images are collected at a frame rate of 30 frames per second.
ro provide a very fast and optimzied user experience. In addition, the
system monitors in real time various quality metrics to determine which

iris image pairs should be selected as the biometric sample.

Capturing the correct position of the eyes is essential for optimal iris biometrics. The system automatically detects subject gaze angle (i.e. whether the subject is looking directly ahead at the imager). If the subject is looking away, the system will automatically wait until the subject looks straight ahead before capturing a valid iris biometric image.

System detects subject eye motion during the capture sequence, and waits until subject meets motion threshold (which is adjustable) in order to assure there is no adverse motion blurring.



Motion detection

Near-real time off-axis gaze

detection

Feature User Advantages

Optional extended range capture Capture range can be extended to 60mm (approximately 300 to 360mm

from subject) through an SDK setting for additional subject ease of use

and capture speed.

Face image capture Face images are collected in synchronization with the biometric iris

images, so that the data record consists of one face image and two iris image. The face images do not qualify as ISO standard, and therefore are not intended for face recognition or an ID card photo, but are intended for manual verification of the subject's identity and association in the

data record with the iris images.

Very wide interpupillary distance

range of 45 to 85 mm

The wide interpupillary distance range accommodates all adults and young children, making it ideal for large scale, public authenti-

cation programs.

User Interface and Subject Instructions

Simplest and most repeatable subject interface available:

- Partially transparent mirror guides subject placement in X-Y dimensions
- Easy to use color LED's at center of mirror indicate correct placement of 32 to 35 cm (enrollment mode) in Z dimension.



move forward



move backward



stop / capture

The subject should be instructed to:

- Place the reflection of his / her eyes in the center of the mirror;
- Keep eyes open;
- Look at the colored LEDs and move his / her head toward or away from system according to the color;
- Stop when LED is green, and hold the position for about 1 second.

Please contact CMITech or your representative for more information on the CMIRIS Software Development Kit (SDK), and the CMITech Demo / Evaluation Package that includes all drivers.

CMITech Company, Ltd.

#904, 25, 248 Beon-gil, Simin-daero, Dongan-gu Anyang-si, Gyeonggi-do, 431-815 Republic of Korea

Tel: +82.70.8633.8277 Fax: +82.31.479.7055

Contact: sales@cmi-tech.com

CMITech America, Inc.

2033 Gateway Place, Suite 500 San Jose, CA 95110 USA Tel: (1) 408 573-6930



Technical Specifications

Dimensions 202 x 94 x 63 mm (8.0 x 3.7 x 2.5 inches)

Weight 465 grams (16.4 ounces) without base

Image output Meets ISO 19794-6; exceeds 4.0 lp/mm @ > 60% contrast

Iris diameter 240 pixels for average 11.5 mm diameter iris

(200 to 285 pixels for full range of 9.5 to 13.5 mm diameter irises)

Iris image pixel resolution 640 x 480 pixels, 8 bits

Supports multiple formats

Operational iris imaging distance

(stand-off range)

315 to 345 mm (12.4 to 13.6 inches) in Normal mode

Depth of field 30 mm (1.2 inches)

Inter-pupillary distance covered 45 to 85mm (1.8 to 3.4 inches)

Extended depth of capture (recognition

mode only)

About 300 to 360 mm. Feature selectable within SDK.

Note: extended depth of capture images may not meet ISO 19794-6 specification.

Time of capture About 0.5 second, typical, from time subject's eyes are placed within capture volume

IR illumination for iris imaging Dual LED: wavelengths of 850 nm nominal

(about 50%); and 750 nm nominal (about 50%)

Color face capture Selectable in SDK.

(The face images do not qualify as ISO standard, and therefore are not intended for face recognition or an ID card photo, but are intended for manual verification of the

subject's identity and association in the data record with the iris images.)

Subject positioning LED indicators Blue: Subject too far away

Red: Subject is too close

Green: Subject within capture volume

Maximum user positioning speed 125 mm per second (4.9 inches per sec.) in "Z" direction

Operating temperature range 0 to 40°C

Humidity 10 to 90% RH, non-condensing

Eye safety standard IEC 62471

Interface USB 2.0 High Speed

Power Independent power supply required: 2.0 A at 5.0 V (supplied with system)

Windows 7, 8, 8.1, and 10 (32 and 64 bit)

Linux Ubuntu 12.04 distribution

Other certifications CE , FCC, RoHS, WHQL

Copyright 2017 CMITech Company, Ltd.—All Rights Reserved.

CMITech Company, Ltd. reserves the right to make changes to specifications and features shown herein, or discontinue the product described at any time without notice or obligation

